

Cytometer Waste Disposal

1. Waste should be emptied each time the cytometer sheath is filled
2. Don gloves and eye protection
3. Remove waste container from the cytometer
4. Transport to laboratory sink
5. Open container and carefully and place inside the sink to pour down the drain with minimal splashing
6. Flush drain for 2 minutes with cold water
7. Add bleach back to the empty waste container for a final concentration of 10% when the waste tank is full.
8. Replace the lid and reconnect to the cytometer.
**LSRII only, leave the lid loose to avoid system back pressure*