



KEY:

-  You Are Here
-  Evacuation Route
-  Exit
-  Restroom
-  Fire Extinguisher
-  Fire Alarm
-  Fire Alarm Control Panel
-  Symbol of Accessibility


IF THERE IS AN EMERGENCY:

- Sound fire alarm.
- Assist persons with disabilities.
- Exit the building using the nearest exit.
- DO NOT USE ELEVATORS!
- Report to the nearest designated outside assembly area.
- Do not re-enter until authorized to do so.






 Fire Alarm Control Panel is located in Switchgear Room #CD11A on Basement Level

CHDD-South
Floor 1

LAKE WASHINGTON SHIP CANAL




KEY:

-  You Are Here
-  Evacuation Route
-  Exit
-  Restroom
-  Fire Extinguisher
-  Fire Alarm
-  Fire Alarm Control Panel
-  Symbol of Accessibility

IF THERE IS AN EMERGENCY:

- Sound fire alarm.
- Assist persons with disabilities.
- Exit the building using the nearest exit.
DO NOT USE ELEVATORS!
- Report to the nearest designated outside assembly area.
- Do not re-enter until authorized to do so.

 Fire Alarm Control Panel is located in Switchgear Room #CD11A on Basement Level

CHDD-South
Floor 2

