

RESERVOIR ASSESSMENT TOOL (RAT)

RATATHON


Ultimate Guide to RAT 3.0

By Sanchit Minocha

with contributions from Pritam Das,
SASWE Group, University of Washington




Analogy: Rivers and Arteries



ARTERIES OF THE BODY






MAN



Analogy: Dams and Heart




Big Picture: How RAT Works?



$$\text{Outflow} = \text{Inflow} - \text{Evaporation} - \text{Storage Change}$$


Reservoir Assessment Tool 1.0



- Reservoir operations monitoring using **publicly available satellite data** and **hydrological modeling**

Biswas et al. (2021)

- Monthly Estimates:
 - Inflow (I): Modeled using VIC
 - Surface Area (A): Landsat 7, 8
 - Storage Change (ΔS): A and Area-Elevation Curve (AEC)
 - Outflow (O): I and ΔS



Reservoir Assessment Tool 2.0

- ☐ More Sensors

 - Optical** – Landsat-8, Sentinel-2

 - SAR** – Sentinel-1

 - Altimetry** – JASON-3

- ☐ Weekly Observations

 - 3-7 Days surface area**

 - 10 Days altimetry**

- ☐ Better Performance using parallel processing

BUT


- ☐ Limited to Mekong Region

- ☐ Not open source


- ☐ Not easy to use

- ☐ Memory Inefficient


Das et al. (2022)




Reservoir Assessment Tool 3.0





- ☐ More Sensors
 - Optical** – Landsat-8 and 9, Sentinel-2
 - SAR** – Sentinel-1
 - Altimetry** – JASON-3
- ☐ Sub-weekly Observations
 - 2-4 Days** surface area
 - 10 Days** altimetry
- ☐ Globally applicable
- ☐ Efficient
- ☐ User-Friendly
- ☐ User-Focused Web Application




Technological Evolution of RAT 3.0



Advancements in RAT 3.0



RAT 3.0 : Requirements



1. A Linux-based system with Python installed and preferably VS Code or any code editor that you like.
 - a) You can download VS Code [here](#).
 - b) Make sure you have downloaded the following utilities in Linux OS:
 - [gfortran](#)
 - [make](#)
 - [miniconda or conda](#)
2. Login credentials for Aviso (**for reservoir height data**)
<https://www.aviso.altimetry.fr/en/data/data-access/registration-form.html>
3. Login credentials for Imerg (**for pulling precipitation data for hydrologic model**)
<https://registration.pps.eosdis.nasa.gov/registration/>
4. Login credentials for Earth Engine using service account (**for reservoir storage change calculation**)
https://developers.google.com/earth-engine/cloud/earthengine_cloud_project_setup

Note: Next section details on how to get login credentials for requirements 2,3 and 4. Follow the instructions and keep the credentials(or password file) handy while installing and initializing RAT 3.0.

IMERG Account Set up

<https://registration.pps.eosdis.nasa.gov/registration/>

Step 1 PPS Registration

Click on **"Register"** to get access to PPS Products.

Fill out the form and click on "Save".

You will get a confirmation e-mail and use it to complete the process.

If you don't receive this e-mail in one hour, please check in your spam folder.

Once you are registered, you can edit your information by entering in your account information contained in the automated email to complete the process.

Please note that by registering to get access to GPM data through PPS, you do not wish to receive system status emails then please do not register for them.

We do not accept email addresses that require us to take a manual action to verify your email address instead.

If you plan to use Near-Real Time (NRT) data stored on jsimpsonftp.pps.eosdis.nasa.gov. Otherwise, your account will only allow access to production data on earthdata.nasa.gov for NRT access. You can add/remove NRT access using the "Verify Email" button.

Please note that your Email will be converted to lower case. Once registered, you can retrieve data from our FTP archives or place orders through STORM.

NEVER reply to an email that is sent to you. If you have questions, please contact the PPS team.

Register

OR

Enter registered email:

Verify Email or Update Info

Remove from access to PPS

Step 2

Please note that your Email will be converted to lower case. Once registration is completed use We do not accept email addresses that require us to take a manual action (Boxbe, etc.). Please

Email *
Confirm Email: *

First Name *
Last Name *

Checking the following box will enable access to the jsimpsonftp.pps.eosdis.nasa.gov FTPS portal.
Please select this option only if you intend to access these products immediately!
Note that, as of 18 June 2020, only FTPS and HTTPS can be used to access NRT data. Standard Research Products
☐ Near-Realtime Products

Please enter a valid organization below. PPS will perform random checks of organizations and

Organization *
Address

☐ Governmental
☐ Non-Governmental Organization
☐ International Organization
☐ University / College
☐ Other Education
☐ Research Institute
☐ Commercial Weather
☐ Insurance
☐ Other Commercial
☐ Private Individual

Organization Type

Area of Interest

Data
Merged RT Products
Tools
TKIO

Check the box below saying that you agree to allow PPS to send you emails relating to system
Allow Emails * ☐


Save

Make sure to check
NRT Products

AVISO Account Set up

<https://www.aviso.altimetry.fr/en/data/data-access/registration-form.html>

Step 1: Fill out the form.




The screenshot shows the AVISO registration form. The top navigation bar includes links for DATA, USER CORNER, APPLICATIONS, MISSIONS, TECHNIQUES, NEWS, and MULTIMEDIA. Below this, a breadcrumb trail shows the path: AVISO+ > DATA > DATA ACCESS > REGISTRATION FORM. The main heading is 'SUBSCRIBE TO GET ACCESS TO AVISO+ PRODUCTS'. Under the 'REGISTRATION' section, the 'PERSONAL INFORMATION' sub-section is active. It contains a note: 'In order to get access to Aviso+ products, an identification process is required. Please, fill in the form and read carefully the licence agreement before accepting it.' Below this, a instruction states: 'Please use standard English characters (A to Z), numbers, '.', ',', '_' and spaces only.' The form fields are: 'Family Name*' (text input), 'First name*' (text input), 'E-mail (in lowercase)*' (text input), and 'Company/Organization*' (text input). A vertical 'BROWSING MENU' is visible on the left side of the form.

Step 2: Select 'GDR/IGDR (Geophysical Data Records)'
In the Product Selection section.

Step 3: Accept the terms and conditions.

Step 4: Submit the form.




The screenshot shows the product selection section of the AVISO registration form. It lists various data products with checkboxes for selection. The products are categorized into several groups:

- Regional X-TRACK Tidal Constants Along-track**
- DAC (Dynamic Atmospheric Correction)**
- Along-track GDP+ Wet tropospheric correction**
- Internal Tide MIOST**
- Coastal, ice and hydrology products:**
 - CFOSAT SWIM Ice products
 - Altimetry Ice Sheet (SGDR+) products
 - Altimetry Sea Ice
 - Coastal and Hydrological products; global (Pistach projects)
 - Experimental Sentinel3 products (PeachI)
 - Coastal Jason-2 DT-SLA; few areas
 - Coastal X-TRACK SLA
- Ssalto/Duacs Delayed-Time:**
 - MSLA Heights: Climatologies and means
 - Ssalto/Duacs Experimental products: along-track and gridded Sea Level Heights and velocities
- Ssalto/Duacs Near-Real Time:**
 - Mozambique MSLA/SLA Heights and Geostrophic velocities UV (grids)
- GDR and GDR-like products:**
 - ☒ GDR / IGDR (Geophysical Data Records)
 - Along-track Experimental Sentinel 6MF products (CNES R&D processor)
- Other products:**
 - Labelled dataset description for SAR S1 images segmentation
 - Sargassum detection products
 - Ocean data challenge
 - Wave experimental products
 - Wave / wind CFOSAT products
 - Sea Level Anomalies Along-track Level-2+ (L2P) Sentinel-3&6
 - Sea Level Anomalies Along-track Level-2+ (L2P) for other missions
 - Wave / wind Along-track Level-2+ (L2P) Sentinel-3&6
 - Wind / Wave Along-track from Geophysical Data Records (L2)
 - Waveform (Radar return echoes in Sensor Geophysical Data Records)

A yellow arrow points from the text 'Step 2: Select 'GDR/IGDR (Geophysical Data Records)'' to the checked checkbox for 'GDR / IGDR (Geophysical Data Records)'.

Google Earth Engine (GEE) Set up



User Account

- ▶ User accounts are normal google account being used by us in day-to-day tasks.
- ▶ saswege@gmail.com is a user account.

VS


Service Account

- ▶ A service account is a special type of Google account intended to represent a non-human user that needs to authenticate and be authorized to access data in Google APIs.
- ▶ sanchit-rat@globalrat.iam.gserviceaccount.com is a service account.


Google Earth Engine (GEE) Set up

When to use Service Account?

- ▶ Running workloads on virtual machines (VMs).
- ▶ Running workloads on on-premises workstations or data centers that call Google APIs.
- ▶ Running workloads which are not tied to the lifecycle of a human user.



Google Earth Engine (GEE) Set up



Task 1- Create a google cloud project

https://developers.google.com/earth-engine/cloud/earthengine_cloud_project_setup

Step 1

Create a Cloud project

★ **Note:** You can create a Cloud Project through the Code Editor as described in the [Code Editor Quickstart](#). If you create a project using the Code Editor, the Earth Engine API is automatically enabled and an Earth Engine assets folder associated with the project is automatically created.

If you haven't already, create a [Google Cloud Project](#). You can do so from the [projects page](#) of the Cloud Console or click the following button:

[Create a Cloud project](#)

You can manage your Google Cloud projects from the [Google Cloud Console](#).

Click on 'Create a Cloud project'

💡 **Tip:** Project name can be something like 'RAT-SE-Asia' or 'RAT Mekong'.

Step 2 Enter a Project name and Click on 'CREATE'.

Google Cloud

Search (/) for resources, docs, products, and more

New Project

You have 11 projects remaining in your quota. Request an increase or delete projects. [Learn more](#)

[MANAGE QUOTAS](#)

Project name *
RAT-South-Asia

Project ID: rat-south-asia. It cannot be changed later. [EDIT](#)


Location *
No organization [BROWSE](#)

Parent organization or folder

[CREATE](#) [CANCEL](#)

Note: Do not close the project window which will open up.

Google Earth Engine (GEE) Set up



Task 2- Enable Earth Engine API

https://developers.google.com/earth-engine/cloud/earthengine_cloud_project_setup

Step 1 Click on 'Enable the Earth Engine API'

Enable the Earth Engine API


To enable the Earth Engine API for your project, click the following button to go to the Earth Engine API page:

Enable the Earth Engine API

On the Earth Engine API page, ensure that you have selected your project, and click **ENABLE**.

You can manage your APIs for a Cloud project from the APIs & Services page of the [Google Cloud Console](#).

Step 2 Make sure the right project is selected and Click on 'ENABLE'.



Google Earth Engine (GEE) Set up



Task 3-Create a service account


Note: In the project window which was opened up while following instructions in the second last page.




Tip: (1) Service account name can be something like 'rat-Mekong-YOUR_NAME' ('rat-mekong-sanchit').
(2) Description can be who will be using this service account and for what.

Step 1


Make sure the right project is selected and Click on 'IAM & Admin' > 'Service Accounts'




Step 2 Click on 'CREATE SERVICE ACCOUNT'



Step 3 Click on 'CREATE AND CONTINUE'




Google Earth Engine (GEE) Set up




Task 3-Create a service account

Step 4

Choose 'Earth Engine' > 'Earth Engine Resource Admin' as first role.




Step 5 Choose 'Service Usage' > 'Service Usage Consumer' as another role and click on 'CONTINUE'. **After that click on 'Done'.**




Google Earth Engine (GEE) Set up


Task 3-Create a service account




Step 6 Click on 'Actions' > 'Manage Keys' for the service account you created.



Step 7 Click on 'Add KEY' > 'Create new key' and select json





Google Earth Engine (GEE) Set up




Task 4A (Recommended, in place of Task 4B) - Register the google cloud project to use Earth Engine

<https://developers.google.com/earth-engine/>

Step 1: Click on 'Register for Earth Engine' (and select your email address if not signed in already). Then click on 'Register a Noncommercial or Commercial Cloud project'.



Google Earth Engine (GEE) Set up



Task 4A (Recommended, in place of Task 4B) - Register the google cloud project to use Earth Engine

<https://developers.google.com/earth-engine/>

Step 2: Select “Unpaid usage” if using for non-commercial activity. Select a suitable ‘Project type’ and click on ‘NEXT’

How do you want to use Earth Engine?

☐ Paid usage
Commercial businesses, government operations. [See examples](#)


☒ Unpaid usage
Non-profits, education, government research, training, media. [See examples](#)

Project type

Please select a project type from the list below:

- Academia & Research
Universities, schools, labs
- Government
Research, certain agencies
- Non-profit
NGOs, charities
- News media
Verified journalists and media organizations
- Trainer & trainees
Earth Engine educational organizations
- No affiliation
Any categories not listed above

Google Earth Engine (GEE) Set up



Task 4A (Recommended, in place of Task 4B) - Register the google cloud project to use Earth Engine

<https://developers.google.com/earth-engine/>

Step 3: Select “Choose an existing Google Cloud Project” and select the cloud project that you created in Task 1. Click on “**Continue to Summary**”.

Step 4: Click on ‘Confirm’ and you can close the window.

Create or choose a Cloud Project to register

Create a new project in Google Cloud, or choose one you are authorized to access to enable the API:

☐ Create a new Google Cloud Project

☒ Choose an existing Google Cloud Project

Type to filter

Refresh

Earth Engine enabled Cloud Projects

Earth Engine	ee-msanchit
--------------	-------------

All Cloud Projects

RAT-South-Asia	rat-south-asia-428321
My First Project	generated-media-328707

Confirm your Cloud Project information


Project usage Academia & Research

Project info rat-south-asia-428321 RAT-South-Asia

BACK CONFIRM

Project information cannot be changed later

Google Earth Engine (GEE) Set up



Task 4B (If Task 4A not done) - Register the service account to use Earth Engine

https://developers.google.com/earth-engine/guides/service_account#register-the-service-account-to-use-earth-engine

Step 1: Click on 'this page' and select your email address.

Register the service account to use Earth Engine

★ If you [use a Cloud project](#) to access Earth Engine, all service accounts in that project with the [correct permissions](#) have access to the EE API, and there's no need to register them separately.

If you don't use a [registered Cloud project to access Earth Engine](#), you can [use this page](#) to register your service account for use with the Earth Engine API. Once you've successfully registered your service account, follow the instructions that appear on the confirmation screen to enable access to the Earth Engine API.

Step 3: Click on submit.

Step 4: Again click on the link mentioned above and follow step 1.

Step 2: Fill out the form and accept the terms.

Email
msanchit@uw.edu
Want to use a different account? [Log out](#) or use an Incognito tab.

Full name *
Please tell us your first and last name.

Affiliation/Institution *
Which organization are you a part of? Give a homepage URL if possible.

Institution type *
Select the best description for your institution, or choose Other and clarify.


Country/Region *
United States
Please tell us where you live.

What would you like to accomplish with Earth Engine? *
Please describe in a few sentences how you intend to use Earth Engine.

This sign-up page is for [noncommercial and research use](#) of Earth Engine.

☐ I agree that my use of the Earth Engine services and related APIs is subject to my compliance with the applicable [Terms of Service](#). In particular, I acknowledge that creating multiple Earth Engine accounts to circumvent quota restrictions is a violation of the Terms of Service.

Google Earth Engine (GEE) Set up



Task 4B (If Task 4A not done) - Register the service account to use Earth Engine

https://developers.google.com/earth-engine/guides/service_account#register-the-service-account-to-use-earth-engine

Step 4: Again click on the link mentioned above and repeat step 1 by clicking on 'this page'.

Register the service account to use Earth Engine

★ If you [use a Cloud project](#) to access Earth Engine, all service accounts in that project with the [correct permissions](#) have access to the EE API, and there's no need to register them separately.

If you don't use a [registered Cloud project to access Earth Engine](#), you can [use this page](#) to register your service account for use with the Earth Engine API. Once you've successfully registered your service account, follow the instructions that appear on the confirmation screen to enable access to the Earth Engine API.

Step 6: Click on 'REGISTER SERVICE ACCOUNT'.

Step 5: Enter the created service account's email address.

Register a new service account for msanchit@uw.edu

Email *


Please enter the service account email address. It should look like foo-project@appspot.gserviceaccount.com or foo-name@project-name.iam.gserviceaccount.com.

REGISTER SERVICE ACCOUNT



Tip: Service account's email address will look something like "[foo-name@project-name.iam.gserviceaccount.com](#)"

RAT 3.0 Installation



1. Create an empty project directory and move into it. Ex - 'rat_project'

```
mkdir rat_project  
cd ./rat_project
```

2. Create a conda environment directory inside project directory. Ex - '.rat_env'

```
mkdir ./rat_env
```

3. Create a conda environment using directory created above

```
conda create --prefix ./rat_env
```

4. Activate this environment using conda


```
conda activate ./rat_env
```

5. Install RAT 3.0 using conda

```
conda install rat -c conda-forge
```



RAT 3.0 Initialization



Initialize RAT using '**rat init**' command.

```
rat init -d . -g -gp <PATH_TO_DOWNLOAD/OF_DOWNLOADED_GLOBAL_DATA> -s <PATH_TO_SECRETS_FILE> -dr google
```

-d or --dir

Put project directory path

OPTIONAL

-g or --global_data

Whether to download global data

OPTIONAL

-gp or --global_data_dir

Path of global database (to download or if existing)

OPTIONAL

-s or --secrets

Put secrets file path (if you have)

OPTIONAL

-dr or --drive

Which drive to download data from (google/dropbox)


OPTIONAL

- ✓ Installs Metsim
- ✓ Installs VIC
- ✓ Download & Compile Routing
- ✓ Download Parameter files
- ✓ Download Global Data (If desired)
- ✓ Automatically Populates Config file



Note: A '**rat_config.yaml**' file is prepared using '**rat_config_template**' in PROJECT_DIRECTORY >> '**Params**' which is created after initializing RAT.

RAT Credentials File



Create a 'secrets.ini' file using a text editor with the following content :


```
#Enter user credentials (email, password) for aviso
[aviso]
username=
pwd=

#Enter user credentials (email, password) for imerg
[imerg]
username=
pwd=

#Enter service account (account_email, path to private json key) for google earth engine
[ee]
service_account=
key_file=
```

Note: A 'secrets_template.ini' file is provided in PROJECT_DIRECTORY >> 'Params' which is created after initializing RAT. Fill in the credentials, rename the file to 'secrets.ini' and save it to PROJECT_DIRECTORY >> 'secrets' or any safe place.

RAT 3.0 Testing



Test RAT using 'rat test' command.

```
rat test -d . -b NUECES -s ./secrets/secrets.ini -dr google
```

- ✓ Download Test data
- ✓ Create test_config.yml file
- ✓ Run RAT for Test data
- ✓ Verifies if RAT has produced outputs as expected.

-d or --dir

Put project directory path

REQUIRED

-b or --basin

Which basin to test RAT on? (NUECES/GUNNISON)

REQUIRED

-s or --secrets

Put secrets file path (if you have)

REQUIRED

-dr or --drive


Which drive to download data from (google/dropbox)

OPTIONAL



Note: A 'test_config.yaml' file is prepared using 'rat_config_template' in PROJECT_DIRECTORY >> 'Params' which is created after initializing RAT.

RAT 3.0 Configuring



Autofill RAT configuration file using 'rat configure' command.

```
rat configure -d . -p ./params/rat_config.yaml -gp <GLOBAL_DATA_DIRECTORY_PATH> -nc <NO_CORES> -s ./secrets/secrets.ini
```

-d or --dir

Put project directory path

REQUIRED

-p or --param

Path of the rat configuration file to update

REQUIRED

-gp or --global_data_dir

Path of downloaded global database

OPTIONAL

-nc or --n_cores

Enter number of cores for RAT to use

OPTIONAL

-s or --secrets

Put secrets file path (if you have)



OPTIONAL

- ✓ Update provided parameter file.
- ✓ Does not prepare a new file.




Note: It is not advised to use configure command with 'rat_config_template.yml'. Make a copy of it and then use the copy to configure.


Directory Structure after RAT Initialization




Outputs of RAT




Steps in RAT 3.0



- ☐ 2 mandatory and 14 optional steps in RAT 3.0
- ☐ Though optional, they should all be run logically (example: Metsim should run before VIC)
- ☐ Optionality gives advantage to skip a step if it's run already for the same dates for that basin
- ☐ If any mandatory step fails, RAT will stop running for that basin
- ☐ If any optional step results in an error, RAT will still try to execute next step given by user




Steps in RAT 3.0



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

Steps in RAT 3.0 – Step (-1)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1

0

1

2

3

4

5

6

7

8

9

10


11

12

13

14

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params as follows:

GLOBAL:

steps: [1,2,3,4,5,6,7,8,9,10,11,12,13,14]

List of step numbers that needs to be executed by RAT. Default is all steps from 1 to 14.

project_dir: *# Main directory path for all RAT models, parameters and global data. RAT Output Data can have a separate directory*


data_dir: *# Data Directory path for RAT output and intermediary files. It can be inside project directory.*

basin_shpfile: *# Basin Shapefile in json/shapefile format which can have multiple basins with unique id.*

basin_shpfile_column_dict: *#example- {'id': 'MRBID'} # Dictionary of column names in basin_shpfile defined above (must have a unique id column)*

Configuration Parameters

Update parameters in 'rat_config' file in 'Project Directory > params' as follows:



BASIN:


region_name: *# Name of the region - used to cluster data for multiple basins within one region*

basin_name: *# Basin name - used for saving data related to that basin*

basin_id: *# Basin id to map the basin in 'GLOBAL:basin_shpfile' # must match with the 'id' column specified through dictionary of column names in 'GLOBAL'*

Configuration Parameters

Update parameters in 'rat_config' file in 'Project Directory > params as follows:



BASIN:

`spin_up: False` # True if vic spin-up is required, otherwise False # True is recommended if it's the first RAT run for a particular basin

`start: #example- 2022-08-01` #yyyy-mm-dd #Start date for RAT excluding any spin-up-time


`end: #example- 2022-08-31` #yyyy-mm-dd #End date for RAT

`vic_init_state_date: #example- 2022-08-18` #yyyy-mm-dd #Date of which initial state of VIC for the particular basin exists #Ignored if first_run is True #It can be left blank if no initial state file exists even when first_run is False

Function: Reading Configuration

- ☐ **Basin Name, Region and ID**
- ☐ **start, end, spin_up, vic_init_state_date**
- ☐ Mostly 'BASIN' section parameters
- ☐ **Basin Shapefile** in 'GLOBAL' section
- ☐ **project_dir** and **data_dir** in 'GLOBAL' section
- ☐ `['CLEAN_UP']['clean_previous_outputs']`
- ☐ **clean_previous_outputs** in 'CLEAN_UP' section

- ✓ Reading these parameters
- ✓ Declaring them globally
- ✓ Starts internal-detailed logging
- ✓ Cleans Previous Outputs (if desired)
- ✓ No Output



-1

0

1

2

3

4

5

6

7

8

9

10


11

12

13

14

Steps in RAT 3.0 – Step (0)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1

0

1

2

3

4

5

6

7

8

9

10

11

12


13

14


Function: Directory Structure

- ☐ Reading paths in the configuration
- ☐ Defining paths globally
- ☐ Creating directories if do not exist

- ✓ Reading some parameters
- ✓ Declaring them globally
- ✓ No Output




Steps in RAT 3.0 – Step (1)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Function: Downloading



☐ Precipitation is downloaded as IMERG late product

☐ In Ascii format

☐ Temperature products are from NOAA Global Daily Temperature


☐ In netcdf format

☐ Wind data is from NCEP/NCAR




☐ In netcdf format

✓ Downloading raw data from servers

✓ Output in **raw**



Function: Preprocessing



☐ Data Downloaded from providers

☐ Scaled

☐ Aligned


☐ Clipped

☐ Stored for further use

✓ Pre-process downloaded data

✓ Output in pre_**processing**

Steps in RAT 3.0 – Step (2)




Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

METSIM

- ☐ Python Package – Meteorological Simulator and forcing disaggregator
- ☐ Simulates weather data
- ☐ Input is Meteorological data : (i) Current data (**metsim_input.nc**)
(ii) 3 months historic data (**state.nc**)
- ☐ Requires 2 parameter files : **domain.nc** and **params.yaml**
- ☐ It's output is required by VIC (**6h_VIC_<start>-<end>.nc**)



Configuration Parameters

Update parameters in 'rat_config' file in 'Project Directory > params' as follows:


METSIM:

`metSIM_env`: # Path of Metsim python environment

`metSIM_param_file`: # Default Metsim configuration parameter file


`metSIM_domain_file`: # Path of Metsim domain parameter file #Required if elevation file is not provided else will be automatically created

`historical_precipitation`: # Path of dataset which has historical precipitation (≥ 3 years) for climatology based correction of satellite precipitation. Optional.



Configuration Parameters

Update parameters in 'rat_config' file in 'Project Directory > params' as follows:




GLOBAL:

`elevation_tif_file:` *# Elevation raster file in tif format. It should be having elevations in meter and in WGS84 crs.*

`multiprocessing:` *# How many CPU cores to use*


`multiple_basin_run:` `False` *# True if running RAT for multiple basins in one go, will require basins_metadata(in csv format) to update any basin particular parameter in this configuration file. This will allow you to run RAT for multiple basins with just one configuration file.*

Function: Merging Data & Metsim Input




- Basin is gridded at a resolution of 0.0625° .
- Basin grid file is created(<basin_name>_grid_mask.tif)
- All preprocessed data is combined into single file (**combined.nc**)
- Metsim inputs:
 - Data from start to end (**metsim_input.nc**)
 - Past 90 days data (**state.nc**)

- ✓ No extra parameter from configuration
- ✓ **Basin grid file** created
- ✓ Data Aggregation
- ✓ **Metsim Input Data**




Steps in RAT 3.0 – Step (3)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series


-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Function: Metsim Parameter




- ☐ Requires elevation file in 'GLOBAL' section
 - ☐ In Tif format
- ☐ Output is metsim domain file (**domain.nc**)

✓ **Metsim domain file created**




Steps in RAT 3.0 – Step (4)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series


-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Function: Metsim Run




- ☐ Updates Metsim Parameter file (**params.yaml**)
- ☐ Runs Metsim using `<n_core>` parallel processing
 - ☐ `<n_core>` defined in 'GLOBAL' section
- ☐ Metsim Output (**6h_VIC_<start>-<end>.nc**)
- ☐ Vic Input (**forcings_<year>.nc**)

- ✓ Runs Metsim
- ✓ **Metsim Output**
- ✓ Prepares **Vic Input**




Steps in RAT 3.0 – Step (5)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

VIC

- ☐ Python Package – Variable Infiltration Capacity Model
- ☐ Macroscale Hydrologic Model to get gridded surface runoff
- ☐ Input is Meteorological forcings : Current data (**forcings_<year>.nc**)
- ☐ Requires 3 parameter files : (i) **vic_domain.nc**
(ii) **vic_soil_param.nc**
(iii) **vic_params.txt**
- ☐ It's output is required by Routing (**nc_fluxes.<start>.nc**)




Configuration Parameters

Update parameters in 'rat_config' file in 'Project Directory > params as follows:

VIC:


`vic_env:` # Path of Vic python environment

`vic_param_file:` # Default vic global configuration parameter file. OPTIONAL. If passed, this file will be used to initialize, but will be over-riden by any options specified in this config file. If not passed, all necessary options must be specified in this file in 'VIC PARAMETERS'.



-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params' as follows:

VIC:

`vic_global_data:` # True if vic global (relative to basin) parameter information is available and should be used


If global (relative to basin) vic parameter information is available and needs to be cropped for the basin [vic_global_data must be True], provide the following three parameters

`vic_global_param_dir:` # Directory of global vic soil and domain parameters # Only required if vic_global_data=True, otherwise ignored

`vic_basin_continent_param_filename:` # Name of the global vic soil parameter file (in netcdf format) # Only required if vic_global_data=True, otherwise ignored

`vic_basin_continent_domain_filename:` # Name of the global vic soil parameter file (in netcdf format) # Only required if vic_global_data=True, otherwise ignored

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params as follows:

VIC:


If basin vic parameter information is available and can be used as it is for basin [vic_global_data must be False], provide the following two parameters

vic_soil_param_file: #Vic Soil Parameter File Path (in netcdf format) # Only required if vic_global_data=False, otherwise ignored

vic_domain_file: #Vic Domain File Path (in netcdf format) # Only required if vic_global_data=False, otherwise ignored

Configuration Parameters

Update parameters in 'rat_config' file in 'Project Directory > params' as follows:



```
##---- VIC Parameters (Optional; must match the option names of [global parameter file of VIC](https://vic.readthedocs.io/en/master/Documentation/Drivers/Image/GlobalParam/)).
##---- If not provided, then the parameter file defined by 'vic_param_file' will be used as the parameter file

VIC PARAMETERS:
# STARTYEAR: '2001'
# STARTMONTH: '04'
# STARTDAY: '02'
# ENDYEAR: '2021'
# ENDMONTH: '04'
# ENDDAY: '01'

# # Any other option goes here
# DOMAIN_TYPE:
#   LAT: lat
#   LON: lon
#   MASK: mask
#   AREA: area
#   FRAC: frac
#   YDIM: lat
#   XDIM: lon
# FORCING1: Directory path for vic/forcing_
# FORCE_TYPE:
#   AIR_TEMP: temp
#   PREC: prec
#   PRESSURE: air_pressure
#   SWDOWN: shortwave
#   LWDOWN: longwave
#   VP: vapor_pressure
#   WIND: wind
# OUTVAR:          # Specify as list
#   - OUT_PREC
#   - OUT_EVAP
#   - OUT_RUNOFF
#   - OUT_BASEFLOW
# RESULT_DIR: Directory path for vic results
```


OPTIONAL

If vic_param_file
is not provided

Function: VIC Parameters


- ☐ Requires **vic_soil_param** and **vic_domain** files
global/basin in 'VIC' section
 - ☐ In Netcdf format
- ☐ Outputs are vic domain file (**vic_domain.nc**) and vic soil parameter file (**vic_soil_param.nc**)

✓ **Vic Parameter Files** are created. (if desired)



-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Steps in RAT 3.0 – Step (6)




Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14


Function: VIC Run

- ❑ Updates VIC Parameter file (**vic_params.yaml**)
- ❑ Runs VIC using **<n_core>** parallel processing
 - ❑ **<n_core>** defined in 'GLOBAL' section
- ❑ Vic Input (**forcings_<year>.nc**)
- ❑ VIC Output (**nc_fluxes_<start>.nc**)
- ❑ Routing Input (**fluxes_<lat>_<lon>**)
- ❑ Creates VIC Init State for end (**state_<end>.nc**)

- ✓ Runs VIC
- ✓ **VIC Output**
- ✓ Prepares **Routing Input**
- ✓ Creates **Vic Initialisation State**



Steps in RAT 3.0 – Step (7)




Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14


Routing

- ☐ Fortran Program
- ☐ Routes surface runoff within a grid cell (in the main channel)
- ☐ Input is Surface Runoff : Current data (**fluxes_<lat>_<lon>**)
- ☐ Requires 4 parameter files : (i) **sta_xy.txt**
(ii) **fl.asc**
(iii) **uh.txt**
(iv) **route_param.txt**
- ☐ It's output is daily Inflow (**<station (initial 5)>.day**)
- ☐ Output converted to daily inflow in metric scale (**< station (initial 5)>.csv**)



Configuration Parameters

Update parameters in 'rat_config' file in 'Project Directory > params' as follows:




ROUTING:

`route_model:` *# Path of routing model*

`route_param_file:` *# Will be used to initialize routing model. If not passed, every option must be specified in 'ROUTING PARAMETERS' section*

-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params' as follows:

ROUTING:

Flow Direction File


If flow direction file (can be global) is available in tif format

global_flow_dir_tif_file : # flow_direction_file in tif format (global compared to basin, so can be cropped)

```
replace_flow_directions : { 1 : 3,  
                             4 : 5, # first replace 4 by 5 and then replace 2 by 4  
                             2 : 4,  
                             8 : 6,  
                             16 : 7,  
                             32  
                             64 : 1,  
                             128 : 2,  
                             255 : 0 } # If no replace is required, leave it blank
```

Important Note: If using global flow direction file provided with RAT, don't change replace flow directions.

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params' as follows:

ROUTING:

```
## Stations File (Each dam is a station)
```

```
## Either provide a global (relative to basin) stations_geojson_file with point geometry  
column and define the column names using dictionary or provide station_latlon file path in  
csv format
```

```
station_global_data : True # True if giving global stations_file and column names, otherwise  
false and give station_latlon_path
```

```
## If station_global_data is True fill the below variables
```

```
stations_vector_file : # Must have geometry(vector) column and separate lat, lon columns
```

```
## Must have unique id_column as primary key. name_column values can be left blank, but the  
column should exist.
```


```
stations_vector_file_columns_dict : {id_column : 'GRAND_ID',
```

```
name_column : 'DAM_NAME',
```

```
lon_column : 'LONG_DD',
```

```
lat_column : 'LAT_DD'}
```

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params as follows:

ROUTING:

Stations File (Each dam is a station)


Or provide a stations_csvfile with columns run, name, lat, lon and name of each station must be unique with no spaces

station_global_data : False # True if giving global stations_file and column names, otherwise false and give station_latlon_path

If station_global_data is False fill the below variable

station_latlon_path: # In lat lon format csv format #should have columns run, name, lat, lon

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params as follows:


ROUTING PARAMETERS: # *(Optional; if passed, will be given the highest priority and will override the default ones calculated by scripts; Otherwise provide them in route_param.txt)*

```
# flow_direction_file: # Will be generated automatically from global_flow_dir_tif_file if
                        given, otherwise uncomment and provide the path here
velocity:              1.5
diff:                  800
xmask:                 5000
fraction:              1
# station_file:        null # Will be generated automatically from either `stations_file`
# input_files_prefix:  null # Will be generated automatically based on vic output
input_file_precision: 2 # Default. Works fine for 0.0625° grid.
# start_date:          null # Will be automatically populated
# end_date:            null # Will be automatically populated
# output_dir:          # Will be generated automatically for each basin
uh:                   # Unit hydrograph file for routing.
```

Function: Routing Parameters


- ☐ Prepares Basin Station File (**basin_station_latlon.csv**)(If desired)
 - ☐ In CSV format
- ☐ Prepares Basin grid flow direction file (**fl.asc**)(If desired)
 - ☐ In Ascii format

✓ **Routing Parameter Files** are created. (if desired)



-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14


Steps in RAT 3.0 – Step (8)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series


-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Function: Routing Run




- ☐ Updates Routing Parameter file (**route_param.txt**)
- ☐ Runs Routing
- ☐ Rout Input (**fluxes_<lat>_<lon>**)
- ☐ Rout Output (**<station (initial 5)>.day**)
- ☐ Inflow (**< station (initial 5)>.csv**)
- ☐ Creates Routing Init State for end (**route_init_state_file<end>.nc**)

- ✓ Runs Routing
- ✓ **Routing Output**
- ✓ Generates **Inflow**
- ✓ **Creates routing initialization state file**




Steps in RAT 3.0 – Step (9)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params as follows:

GEE:

```
## All reservoir polygons in one shapefile with a column(s) mapping to  
station/dams and having dam area in square km
```

```
reservoir_vector_file :
```

```
## If station_global_data is True, id_column and dam_name_column values should  
match with the values of id_column and name_column of stations_vector_file.
```



```
## If station_global_data is False, values of dam_name_column should match with  
the name column in station_latlon_path or station_file in Routing or Routing  
Parameters.
```

```
## If station_global_data is False, id_column field is not required below, can  
be left blank.
```

```
reservoir_vector_file_columns_dict : {id_column : 'GRAND_ID', dam_name_column :  
                                     'DAM_NAME', area_column : 'AREA_SKM'}
```


GEE Surface Area

- ☐ Google Earth Engine API
- ☐ Uses TMS-OS to calculate surface area of a reservoir
- ☐ Uses Sentinel-1, Sentinel 2, Landsat 8 & 9
- ☐ Do batch wise Extraction (Example 5 days)
- ☐ It's output is surface area timeseries (<station>.csv)
- ☐ As of now it works for after 2019 time period.



-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Function: Surface Area Parameters


- ☐ Filters the reservoirs which are within basin
 - ☐ Filtered using <reservoir_vector_file> provided in 'GEE' section
- ☐ Prepares Basin Reservoir Shape File (**basin_reservoirs.shp**)
 - ☐ In Shapefile format

✓ **Surface Area Parameter Files** are created.
(if desired)



-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Steps in RAT 3.0 – Step (10)




Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series


Function: GEE Run

- ☐ Connects to Earth Engine
- ☐ Calculates Surface Area using Sentinel 1,2 & landsat 8,9
- ☐ Applies TMS-OS algorithm
- ☐ Surface area time series Output (<station>.csv)

- ✓ Runs Surface Area Calculation Script
- ✓ **Surface Area Time Series Output**



Steps in RAT 3.0 – Step (11)






Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Altimeter Height Extraction

- ☐ Radar based technology
 - ☐ Active sensor pings the water surface
- ☐ Jason-3 data
 - ☐ 10 day frequency
- ☐ Low spatial Coverage
- ☐ Highly Accurate
- ☐ Future Missions : SWOT



Configuration Parameters


Update parameters in 'rat_config' file in 'Project Directory > params' as follows:

ALTIMETER:


`altimeter_tracks:` *## altimeter track paths in geojson format*

`geoid_grid:` *## geoid egm grid data in matlab file*

`last_cycle_number:` 226



Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params' as follows:

ALTIMETER:

```
## Unique ids of reservoirs to process for altimeter for a basin in csv format with column  
name 'reservoir_uni_id'
```

```
## You can specify min and max latitudes for ROI in this file with column name 'min_lat' and  
'max_lat'
```

```
## If station_global_data is True, these ids should match with 'uniq_id' values in  
basin_reservoir shapefile generated automatically
```

```
## If station_global_data is False, these ids should match with dam_name_column in  
reservoir_vector_file
```

reservoirs_csv_file:


```
## If you want to use the above file only to specify range of latitude and not the list of  
reservoirs to process for altimeter
```

```
only_for_range: False
```


Function: Altimetry Run

- ☐ Downloads raw altimetry data
- ☐ Find reservoirs on the altimeter track path
 - ☐ Can be provided manually
- ☐ Processes data to extract height (depth) of reservoirs
- ☐ Outputs depth time series (<reservoir>.csv)

- ✓ Runs Surface Area Calculation Script
- ✓ **Surface Area Time Series Output**




Steps in RAT 3.0 – Step (12)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series


Area Elevation Curve



- ☐ Relation between water level and surface area for a reservoir
- ☐ Can be obtained using satellite data
- ☐ If possible, get in-situ data



Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params' as follows:

POST_PROCESSING:

Folder path containing aec csv files for all reservoirs with the file names should be unique_identifiers.


If station_global_data is True, these unique_identifiers should match with 'uniq_id' values in basin_reservoir shapefile generated automatically

If station_global_data is False, these ids should match with dam_name_column in reservoir_vector_file


If the folder path is not present or some reservoir aec file is not present, it will be generated automatically

aec_dir:


Function: Area Elevation Curve Estimation



- ☐ GEE script to extract area elevation curve
 - ☐ Uses DEM defined in 'GLOBAL' section
 - ☐ SRTM 30 m global resolution
 - ☐ Bathymetry gets extrapolated
- ☐ Outputs area elevation curve file for each reservoir (**<reservoir>.csv**)



Steps in RAT 3.0 – Step (13)



Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series

-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Function: Post Processing

☐ Storage Change(ΔS) Calculation (Trapezoidal Method)

- ☐ Requires : (i) Area Elevation Curve (<reservoir>.csv)
- (ii) Surface Area Time Series (<reservoir>.csv)

☐ Output : Storage Change (<reservoir>.csv)

☐ Evaporation Calculation (Penman's Equation)





- ☐ Requires : (i) VIC Output – grided surface (<reservoir>.csv)
- (ii) Surface Area Time Series (<reservoir>.csv)

☐ Output : Evaporation (<reservoir>.csv)

☐ Outflow Calculation(Mass Balance Approach)


- ☐ Requires : (i) Inflow (<reservoir>.csv)
- (ii) Storage Change (<reservoir>.csv)
- (iii) Evaporation (<reservoir>.csv)

☐ Output : Evaporation (<reservoir>.csv)




-1
0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

Steps in RAT 3.0 – Step (14)




Step Number	Step Name
-1	Reading Configuration settings to run RAT
0	Creating required directory structure for RAT
1	Downloading and Pre-processing of meteorological data
2	Pre-processing of data and preparation of MetSim Input
3	Preparation of MetSim Parameter Files
4	Running MetSim & preparation of VIC input
5	Preparation of VIC Parameter Files
6	Running of VIC and preparation of Routing input
7	Preparation of Routing Parameter Files
8	Running Routing
9	Preparation of parameter files for Surface Area Calculation
10	TMS-OS Surface Area Calculation from GEE
11	Elevation extraction from Altimeter
12	Generating Area Elevation Curves for reservoirs
13	Calculation of Outflow, Evaporation, Storage change and Inflow
14	Conversion of output data to final format as time series


Function: Final Outputs & Cleaning



- ☐ Generating Final outputs
 - ☐ Website frontend compatible
- ☐ Cleans intermediate files that will not be useful next time
 - ☐ Saves memory
 - ☐ Keeps RAT outputs to append next time



Configuration Parameters



Update parameters in 'rat_config' file in 'Project Directory > params' as follows:

CLEAN_UP:

clean_preprocessing: `False` # Deletes pre-processing data except global raw data

clean_metsim: `False` # Deletes metsim outputs

clean_vic: `False` # Deletes vic inputs and outputs as well as previous vic_init_states


clean_routing: `False` # Deletes routing inputs and outputs

clean_gee: `False` # Deletes unnecessary small chunk files downloaded using gee; not deleting the combined file, To delete the combined file use clean_previous_outputs

clean_altimetry: `False` # Deletes raw altimetry data which takes a lot of time to download; does not delete the extracted altimetry data, to delete extracted altimetry data use clean_previous_outputs

clean_previous_outputs: `False` # Deletes previous rat_outputs, routing inflow, gee extracted area and altimetry extracted heights

Multiple Basin Run



Update parameters in 'rat_config' file in 'Project Directory > params as follows:


GLOBAL:

basins_metadata: *# A csv file which is multi-indexed and have same indexing as rat_config.yml
Only required if multiple_basin_run is true, otherwise ignored*

basins_to_process: *#example- ['basin1','basin2'] # List of basin names to process if
multiple_basin_run is true, otherwise ignored (must match with index 'BASIN: basin_name:'
defined in basins_metadata csv file)*


Multiple Basin Run

This is a sample for basins_metadata file



First Index	BASIN ▼	BASIN ▼	BASIN ▼	VIC ▼	VIC ▼
Second Index	region_name	basin_name	basin_id	vic_basin_continent_param_filename	vic_basin_continent_domain_filename
	Texas	SABINE	4233	namerica_params.nc	namerica_domain.nc
	Texas	TRINITY	4247	namerica_params.nc	namerica_domain.nc
	Texas	BRAZOS	4203	namerica_params.nc	namerica_domain.nc
	Texas	COLORADO	4209	namerica_params.nc	namerica_domain.nc
	Texas	SAN ANTONIO	4239	namerica_params.nc	namerica_domain.nc
	Texas	NUECES	4223	namerica_params.nc	namerica_domain.nc
	Texas	RIO GRANDE	4231	namerica_params.nc	namerica_domain.nc

Summarized workflow of RAT 3.0



Run RAT 3.0



Command
Line

Test RAT using 'rat test' command.

```
rat run -p ./rat_project/params/rat_config.yml -o 3
```

Put rat configuration file
path

REQUIRED

Number of days for
operational latency

OPTIONAL

Should be provided
only if RAT has already
run once for a
particular basin


✓ Runs RAT either once or
operationally

Python

```
from rat.run_rat import run_rat  
run_rat(config_fn = './rat_project/params/rat_config.yml', operational_latency=None)
```


Thank You

"Let RAT help you TRACK"



www.satellitedams.net